

WHAT IS BOOST?

GENERAL PRINCIPLE


Enlarged wheel dish allows:

- Greater wheel lateral stiffness
- Wider bottom bracket with the same Q-Factor → more tyre clearance → shorter chainstays → more dynamic bike

DIMENSIONS

- Front: 15x110mm (+5mm on each side)
 - Rear: 12x148mm (+3mm on each side)
- Wheels can't convert from Boost to Standard and vice-versa

FRONT WHEELS



REAR WHEELS

